



QEPParts.com
888-634-4289
An iBuy Stores Company

Ref. No.	Part No.	Description
1.	40272	Body - R.H.
2.	40273	Body - L.H.
3.	40061	Extension Handle (Includes #38)
4.	40220	Tongue Nailing Shoe
5.	40153	Tongue Nailing Shoe Base (2 ea)
6.	2598	Tongue Nailing Shoe Base Screws (4 ea)
7.	40223	Face Shoe
8.	40224	Face Shoe Base
9.	40226	Face Shoe Base Screws (4 ea)
10.	40043	Shoe Screws (4 ea)
11.	40040	Wear Plate / Shear Plate Dowels (2 ea)
12.	54580	Wear Plate
13.	40170	Shear Plate
14.	53849	Pusher Spring Roll Pin 1/8 x 5/8
15.	-----	Pusher Spring Tube (See Ref. No. 48)
16.	40146	Pusher Spring
17.	40093	Connector
18.	40109	Rail Spring Pin 1/8 x 3/8
19.	40151	Rail
20.	40094	Pusher
21.	40030	Rubber Ram Cap
22.	40116	Ram (Includes #'s 21,24,26)
23.	40131	Driver Blade
24.	40052	Ram Washer
25.	40124	Ram Spring Guide
26.	40126	Ram Spring
27.	40245	Ram Guide
28.	40050	Ram Stop Screws (2 ea)
29.	40241	Shoulder Screw (Includes #30)
30.	802194	Shoulder Screw Nut
31.	2190	Pawl Housing Set
32.	40101	Pawl Spring

Ref. No.	Part No.	Description
33.	40037	Pawl
34.	40115	Ram Stop Springs (2 ea)
35.	40048	Ram Stop Block
36.	40243	Nailer Body Screws (4 ea)
37.	40244	Body Handle Screws (3 ea)
38.	1165	Extension Handle Fasteners
39.	40229	Thin Flooring Shoe
40.	40152	Thin Flooring Shoe Base
41.	2600	Thin Flooring Shoe Base Screws (4 ea)
42.	40221	Tongue Nailing Shoe Assembly (Includes #'s 4, 5, 6)
43.	40225	Face Shoe Assembly (Includes #'s 7, 8, 9)
44.	40230	Thin Flooring Shoe Assembly (Includes #'s 39,40, 41)
45.	40008	Hammer (Not Shown)
46.	840080	Spare Parts Package (Not Shown; Includes #'s 24, 26)
47.	2191	Pawl Housing Assembly (Includes # 31, 32, 33)
48.	40097	Pusher Spring Tube Assembly (Includes #'s 15, 16, 17)
49.	59561	Starter Parts Kit (Incluye #'s 12, 13, 20, 21, 23, 24, 25, 26, 32, 33)